



OPUS HobbyCUT A4

PL Instrukcja obsługi

1 ZASADY BEZPIECZEŃSTWA

- Przed rozpoczęciem pracy z urządzeniem, należy zapoznać się z zasadami bezpieczeństwa, zaleceniami producenta i instrukcją obsługi. Instrukcję należy zachować i korzystać z niej w przypadku jakichkolwiek wątpliwości dotyczących obsługi urządzenia.
- Urządzenie służy wyłącznie do cięcia papieru. Papier specjalny (np. kredowany) lub karton należy ciąć pojedynczo.
- Nie należy ciąć jednorazowo większej ilości papieru niż ilość maksymalna (patrz: Dane techniczne).
- Urządzenie należy trzymać z dala od dzieci i zwierząt.
- Urządzenie posiada ostre elementy tnące należy zachować szczególną ostrożność przy wykonywaniu cięcia, istnieje ryzyko skaleczenia.
- Przy wykonywaniu cięcia należy zwrócić szczególną uwagę na luźne elementy garderoby.
- Urządzenie należy ustawić na płaskiej, stabilnej powierzchni.

2 MONTAŻ

Przed rozpoczęciem pracy należy zamocować do urządzenia plastikową osłonę noża. W tym celu należy umieścić obcinarkę na płaskiej powierzchni, a następnie krańce plastikowej osłony umieścić w otworach znajdujących się w obudowie urządzenia, tuż przy nożu.

3 OBSŁUGA

Podnieść RAMIĘ noża i wsunąć papier pod ostrze noża. Za pomocą skali naniesionej na metalowej podstawie wybierz miejsce cięcia. W trakcie przecinania papieru dociśnij go do blatu, tak aby przypadkowo się nie przesunął.

4 DANE TECHNICZNE

Obcinarka OPUS HobbyCUT A4 przecina maks. do:.....5 kartek (70 g/m²)
Długość cięcia:.....320 mm
Posiada listwę dociskową oraz metalową podstawę
Wymiar stołu roboczego (S x G):.....320 x 150 mm
Wymiary (W x S x G):.....42 x 410 x 170 mm
Waga netto:.....0,9 kg
Waga brutto:.....1,1 kg
Obcinarki testowano na papierze w formacie A4 o gramaturze 70 g/m²

Wyprodukowano w Tajwanie dla OPUS Sp. z o.o.

Producent: OPUS Sp. z o.o., ul. Toruńska 8, 44-122 Gliwice, Polska, info@opus.pl, www.opus.pl

26.03.2025



OPUS HobbyCUT A4

EN User guide

1 HEALTH & SAFETY PRECAUTIONS

- Before using the equipment please read the Health & Safety precautions, manufacturers' recommendations and the operating manual.
- The operating manual should be available at all times for the operator to read.
- The equipment is intended for cutting paper only. None standard paper, e.g. coated paper, chalked paper or card should be cut one piece at a time.
- The equipment should be kept out of reach of children and animals.
- Do not exceed maximum number of sheets..
- **Danger!! The equipment contains sharp elements – pay special attention during cutting.**
- Keep loose-fitting clothes away from the trimmer during operating.
- The equipment must be used on a strong and sturdy surface.

2 INSTALLATION

Put the equipment on a firm, solid surface and mount plastic blade guard before use. To install the blade guard, blade guard should be parallel to the blade, put the edges into special holes in the housing.

3 OPERATION

Lift the blade handle up and slide the paper to be cut under the safety guard. Using scale adjust paper to desired position. Press the paper to the base with your hand and push the blade down.

4 TECHNICAL DATA

Trimmer OPUS HobbyCUT A4 cuts up to:.....5 sheets (70 g/m²)
Cutting length:.....320 mm
Equipped with clamp bar and metal working base
Dimensions:.....H 42 x W 410 x D 170 mm
Dimensions of base:.....W 320 x D 150 mm
Net weight:.....0.9 kg
Gross weight:.....1.1 kg
Trimmmers were tested on 70 g/m² paper, A4 format